


Model of your monitor

 7 inch LCD universal pillow

Install



The circuit connection of the pillow monitor is very simple. Connect the plug to the jacket of the video signals, hide the connector in the base.



How to use the accessory tubes

As pillow holes are different sizes, this product is provided with two type tubes 12mm and 12.7mm in diameter. When the pillow hole is large, fit the suitable one fitting to different needs.

Thanks for your support. To ensure long-term trouble-free service of the product, please read this Manual carefully before using the monitor.

Headrest TFT LCD monitor

USER'S MANUAL



Before operating the Monitor, please read this manual thoroughly and retain it for **future reference**